

innoliving

**BILANCIA DA CUCINA
DIGITALE CON CIOTOLA**



INN-132
MANUALE D'USO
USER MANUAL



BILANCIA DA CUCINA DIGITALE CON CIOTOLA

I

MANUALE D'ISTRUZIONE

Vi ringraziamo per aver acquistato la bilancia da cucina INN-132, un valido aiuto in cucina per pesare cibi ed ingredienti rapidamente e con la massima precisione. Prima di procedere all'utilizzo del prodotto è importante leggere attentamente le istruzioni. Si consiglia di conservare questo manuale per un utilizzo futuro

AVVERTENZE

- Questo prodotto è destinato solo all'uso per cui è stato concepito, e cioè come bilancia elettronica per uso esclusivamente domestico. Ogni altro utilizzo è da considerarsi improprio e pertanto pericoloso. La presente bilancia non è utilizzabile per determinare il peso di oggetti o sostanze nelle transazioni commerciali, per la fabbricazione di medicine, per il calcolo di pedaggi, tariffe, tasse, premi, ammende, remunerazioni, indennità o canoni di tipo analogo determinati in funzione del peso.
- Gli elementi di imballaggio (sacchetti di plastica, cartone, polistirolo ecc.) non devono essere lasciati alla portata dei bambini in quanto potenziali fonti di pericolo e devono essere smaltiti secondo quanto previsto dalle normative vigenti.
- Posizionare la bilancia su una superficie piana e stabile. Non utilizzare la bilancia in prossimità di telefoni cellulari, radio, computer o qualsiasi altro dispositivo elettronico.
- Il display visualizza "EEEE" se il peso supera la portata massima di 5.000 g, rimuovete immediatamente il peso dalla bilancia per evitare di danneggiare le celle di carico.
- In caso di malfunzionamento, rimuovere e installare nuovamente la batteria. Se il problema persiste, rivolgersi ad un centro assistenza autorizzato per la riparazione.
- Non aprire o manomettere l'apparecchio: le riparazioni devono essere eseguite solo da personale autorizzato.
- Non appoggiare nessun oggetto nel contenitore, quando la bilancia non è in funzione.
- In quanto strumento di precisione, la bilancia deve essere trattata sempre con cura. Non sottoporla ad urti e non farla cadere.
- Dopo aver acceso la bilancia, attendere qualche secondo per dare la possibilità ai componenti interni di stabilizzarsi prima di pesare.
- Maneggiare con cura, posizionare delicatamente tutti i prodotti da pesare nel contenitore.
- Tenere in un luogo pulito e asciutto. Polvere, sporco, umidità, vibrazioni, correnti d'aria e la vicinanza ad altri apparecchi elettronici possono provocare un effetto negativo sull'affidabilità e la precisione della bilancia.
- Se il prodotto non viene utilizzato per un lungo periodo di tempo, si consiglia di rimuovere le batterie, in quanto una possibile perdita di liquido potrebbe danneggiarlo.
- Se le misurazioni dovessero sembrare sballate, verificare innanzitutto che le batterie facciano bene contatto. Sostituire le batterie se necessario e provare nuovamente. Se il problema persiste, contattare il centro assistenza.

CARATTERISTICHE TECNICHE

- Capacità: 5kg
- Divisione: 1g
- Unità di misura: g/lb/oz/kg
- Ampia ciotola in plastica
- Display LCD retroilluminato
- Indicatore batteria scarica
- Indicatore sovrappeso
- Funzione tara
- Alimentazione: 2 batterie di tipo AAA incluse.

3

DESCRIZIONE PRODOTTO

Ciotola



Tara ON/OFF

Selezione unità di misura

ISTRUZIONI PER L'USO

- Rimuovere l'imballaggio dalla bilancia, aprire il vano batterie ed inserire le batterie.
- Posizionare la bilancia su una superficie piana e stabile.

RILEVAMENTO PESO

1. Premere il tasto "TARA" per accendere il prodotto, uno '0' apparirà sul display dopo alcuni secondi.
2. Posizionare la ciotola sulla bilancia, il display mostrerà il peso del contenitore.
3. Premere nuovamente il tasto "TARA", sul display apparirà uno '0'. Inserire il cibo nella ciotola, il peso netto apparirà nel display.
4. Premere "UNIT" per cambiare l'unità di misura in kg/g/lb/oz

SIMBOLI SUL DISPLAY

- Quando sullo schermo appare "LO", significa che la batteria si sta scaricando; si prega quindi di procedere con il cambio batterie appena possibile.
- Quando la bilancia è in sovraccarico, sul display appare "EEEEE".

BATTERIE

- Utilizzare 2 batterie di tipo AAA
- Per cambiare le batterie, aprire l'apposito vano sul retro della bilancia e inserire le 2 batterie di tipo AAA
- Rispettare le polarità indicate nel vano batterie e richiudere.

PULIZIA E MANUTENZIONE

Non immergere mai la base della bilancia nell'acqua, né metterla sotto il getto diretto dell'acqua. Pulire con un panno umido: evitare qualsiasi infiltrazione d'acqua. Non utilizzare mai detergenti chimici. Procedere con la pulizia subito dopo l'uso qualora si notino macchie di grasso, cibi, tracce di aceto o alimenti dalle colorazioni scure. Evitare il contatto con sostanze contenenti acido citrico. La ciotola può essere lavata in acqua, ma deve sempre essere rimossa dalla base e asciugata accuratamente.

Tenere al riparo da polvere e umidità; non esporre al sole o a temperature eccessive.

ETICHETTA DATI

innoliving
Innoliving Spa - Via Merloni 2/B - 60131 Ancona - Italy
INN-1320 BILANCIA DIGITALE DA CUCINA
DIGITAL KITCHEN SCALE
MAX: 5 Kg DIV: 1g 3V⁻⁻⁻ 2x AAA batt.
SOLO USO DOMESTICO - HOUSEHOLD USE ONLY
MADE IN CHINA
LOT.



innoliving
Innoliving Spa - Via Merloni 2/B - 60131 Ancona - Italy
INN-132G BILANCIA DIGITALE DA CUCINA
DIGITAL KITCHEN SCALE
MAX: 5 Kg DIV: 1g 3V⁻⁻⁻ 2x AAA batt.
SOLO USO DOMESTICO - HOUSEHOLD USE ONLY
MADE IN CHINA
LOT.



innoliving
Innoliving Spa - Via Merloni 2/B - 60131 Ancona - Italy
INN-132Y BILANCIA DIGITALE DA CUCINA
DIGITAL KITCHEN SCALE
MAX: 5 Kg DIV: 1g 3V⁻⁻⁻ 2x AAA batt.
SOLO USO DOMESTICO - HOUSEHOLD USE ONLY
MADE IN CHINA
LOT.




Questo prodotto è conforme a tutte le direttive europee applicabili



Per contatto con alimenti



INFORMAZIONI AGLI UTENTI ai sensi del Decreto Legislativo N° 49 del 14 Marzo 2014 "Attuazione della Direttiva 2012/19/UE sui rifiuti di apparecchiature elettriche ed elettroniche (RAEE)".

Il simbolo del cassonetto barrato riportato sull'apparecchiatura indica che il prodotto alla fine della propria vita utile deve essere raccolto separatamente dagli altri rifiuti. L'utente dovrà, pertanto, conferire l'apparecchiatura integra dei componenti essenziali giunta a fine vita agli idonei centri di raccolta differenziata dei rifiuti elettronici ed elettrotecnici, oppure riconsegnarla al rivenditore al momento dell'acquisto di nuova apparecchiatura di tipo equivalente, in ragione di uno a uno, oppure 1 a zero per le apparecchiature aventi lato maggiore inferiore a 25 CM. L'adeguata raccolta differenziata per l'avvio successivo dell'apparecchiatura dimessa al riciclaggio, al trattamento e allo smaltimento ambientale compatibile contribuisce ad evitare possibili effetti negativi sull'ambiente e sulla salute e favorisce il riciclo dei materiali di cui è composta l'apparecchiatura. Lo smaltimento abusivo del prodotto da parte dell'utente comporta l'applicazione delle sanzioni amministrative di cui al D.Lgs n. Decreto Legislativo N° 49 del 14 Marzo 2014.



Le batterie utilizzate da questo apparecchio, alla fine della loro vita utile, vanno smaltite negli appositi raccoglitori. Informarsi sulle normative locali relative alla raccolta differenziata delle batterie. Un corretto smaltimento delle batterie permette di evitare conseguenze negative per l'ambiente e la salute.

INSTRUCTION MANUAL

Thanks for choosing digital kitchen scale INN-132, a reliable Kitchen aid to weigh ingredients and food quickly and accurately. In order to ensure the correct usage of the scale, it is advisable to read carefully this instruction manual. It is also advisable to save this manual for a future use.

WARNINGS

- Use this product only for its intended purpose, as described in this instruction manual such as an electronic scale for domestic use only. Any other use should be considered improper and dangerous. This scale should not be used to weigh objects or substances in commercial transactions, to produce medicines, to calculate tolls, tariffs, taxes, premiums, fines, remunerations, indemnities or fees of a similar kind determined by weight.
- Packaging components (plastic bags, cardboard, polystyrene etc.) must be kept out of the reach of children as they might be dangerous and their disposal should be carried out according to the current regulations.
- Place always the product on a flat and stable surface. Do not operate near cell phones, radios, computers, or any other electronic device.
- The display shows "EEEE" when the weight is over 5.000 g, remove immediately the weight from the scale, in order to prevent any damage of load cells.
- If the scale doesn't work, remove and install the batteries. If it still doesn't work, please address to a specialized service centre.
- Never try to repair the scale by yourself but always address to specialised centres.
- When the scale is switched off, never place or lay any objects on it.
- Avoid shaking, dropping or shocking the scale. This is a precision instrument and must be handled with care.
- Allow sufficient warm up time. Turn the scale on, wait few seconds to give the internal components a chance to stabilize before weighing.
- Handle with care, gently apply all items to be weighed onto tray top.
- Store and keep the scale in a clean and dry environment. Dust, dirt, moisture, vibration, air currents and proximity to other electronic equipment might affect the reliability and accuracy of your scale.
- Although this scale is designed to be durable, try to avoid rough treatment as this may permanently damage the internal sensor and void your warranty.
- If the unit is not used for a long period of time, it is advisable to remove batteries, their leaking might damage the appliance.

TECHNICAL SPECIFICATIONS

- Capacity: 5kg
- Division: 1g
- Unit of Measure: g/lb/oz/kg
- Wide Plastic Bowl
- Backlighted LCD Display
- Low battery indicator
- Overload indicator
- Tare Function
- Power: 2 AAA batteries included.

PRODUCT DESCRIPTION



HOW TO USE

- Remove the packaging material from the scale, open the battery compartment and insert/replace 2 AAA batteries, respecting the polarities
- Place the scale on a flat and stable surface.

MEASUREMENT

1. Press "TARE" button to turn on the device, a '0' will appear on the display after a few seconds.
2. Place the bowl on the scale, the display will show the weight of the container.
3. Press the button "TARE", the display will show a '0'. Place the food in the bowl, the net weight will appear in the display.
4. Press "UNIT" to change the unit of measure in kg/g/lb/oz.

DISPLAY ERROR

- When the display shows "LO", it means the battery is low; so please proceed to change batteries as soon as possible.
- When the scale is overloaded, the display shows "EEEEEE".

BATTERIES

- Use 2 AAA batteries
- To change the batteries, open the compartment on the back of the balance and insert 2 AAA batteries
- Make sure to respect the polarities indicated in the battery compartment and close

CLEANING AND MAINTENANCE

Never dip the base of the scale into water. Please clean the appliance with a damp and soft cloth avoiding any water seepage inside the scale. Do not use chemical detergents. Clean the scale and bowl immediately after contact with fat, vinegar and strongly flavoured/coloured food. Avoid contact with acid citrus juices.

The bowl can be washed but always remove it from the base before cleaning. It is advisable to store the scale in a clean place. Dust, dirt, moisture, vibration, air currents, can all cause an adverse effect on the reliability and accuracy of your scale.

RATING LABEL:**innoliving**

Innoliving Spa - Via Merloni 2/B - 60131 Ancona - Italy

**INN-132O BILANCIA DIGITALE DA CUCINA
DIGITAL KITCHEN SCALE**

MAX: 5 Kg DIV: 1g 3V \equiv 2x AAA batt.

SOLO USO DOMESTICO - HOUSEHOLD USE ONLY

MADE IN CHINA

LOT.

**innoliving**

Innoliving Spa - Via Merloni 2/B - 60131 Ancona - Italy

**INN-132G BILANCIA DIGITALE DA CUCINA
DIGITAL KITCHEN SCALE**

MAX: 5 Kg DIV: 1g 3V \equiv 2x AAA batt.

SOLO USO DOMESTICO - HOUSEHOLD USE ONLY

MADE IN CHINA

LOT.

**innoliving**

Innoliving Spa - Via Merloni 2/B - 60131 Ancona - Italy

**INN-132Y BILANCIA DIGITALE DA CUCINA
DIGITAL KITCHEN SCALE**

MAX: 5 Kg DIV: 1g 3V \equiv 2x AAA batt.

SOLO USO DOMESTICO - HOUSEHOLD USE ONLY

MADE IN CHINA

LOT.



This product complies with all applicable European directives



Food Contact




INFORMATION TO USERS according to Legislative Decree No. 49 of March 14, 2014 " 2012/19/UE Implementation of the Directive on Waste Electrical and Electronic Equipment (WEEE) "

The crossed-out dustbin symbol indicates that the product at the end of its life must be collected separately from other waste. The user should, therefore, take the equipment with the essential components at the end of its useful life to the separate collection center of electronic and electrical waste, or return it to the retailer when purchasing new equipment of equivalent type, in ratio of one to one, or one to zero for devices with larger side less than 25 CM. The separate collection for the decommissioned equipment for recycling, treatment and environmentally compatible disposal contributes to avoid possible negative effects on the environment and human health and promotes recycling of the materials. Improper disposal of the product by the user entails the application of administrative sanctions according to Legislative Decree No. 49 of 14 March 2014.



The batteries used in this device must be disposed of in the special bins at the end of their life. Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps preventing potentially negative consequences on the environment.





innoliving

Innoliving Spa
Via Merloni, 2/B
60131 Ancona Italy
Tel 071 2133550
www.innoliving.it

MADE IN CHINA



Rev.01_06.2021

